


Ultra Thin Full Rise Scissor lift



Please read this manual carefully before operating this equipment

CONTENTS

Chapter I Safety Instructions	1
Chapter II product features & parameters	
product features	2
Chapter III Installation preparation	6
Chapter IV Adjustment	12
Chapter V Maintenance	18
Chapter VI product explosive diagram	20

Chapter I Safety Instructions

When you use the lift, you must ensure that you have fully read this manual, including installation, operation, safety and other related content.

2. If any abnormal problem is found with the lift, stop using it.

3 Do not overload the lift, the rated capacity of the lift is 3.5 Ton

4 Only trained personnel can operate the lift. It is forbidden to allow car customers or people without operating experience to operate the lift randomly

5. The rubber pad of the small scissor lift must be in contact with the support point of the vehicle, otherwise the vehicle chassis will be damaged. (If you do not know the position of the support point, it is recommended to consult the vehicle manufacturer by telephone)

6. After the car is lifted, the mechanical locking action must be performed, and it is prohibited to work under the vehicle without the mechanical lock locked well.

7 The surrounding area of the lift must be clean and tidy. Any obstacle such as oil pollution is a safety hazard.

8. It is prohibited to lift the vehicle when there are people in the vehicle.

9 Before lowering the vehicle, make sure there are no obstacles underneath.

10 When the hydraulic system is under pressure, it is forbidden to disassemble any hydraulic parts.

11. Do not put your hands in any dangerous point such as between knife arms

12. This product is only suitable for indoor use, and it is forbidden to use it outdoors.

13 Keep pressing the down button when descending. The platform automatically rises for a short period and the insurance is opened. automatic descent.

14. The operator must wear safety shoes to operate the lift.

15 It is prohibited to lift the car with people in the car.

16 When the lift not work, cutoff the power.

17 When the vehicle is getting on and off the lift, it is forbidden for people to stand on the aisle of getting on and off the vehicle.

18. Before the vehicle leaves the lift, confirm that the lift platform has been lowered to the lowest position.

19. Carefully read each item on the operation warning label.

Chapter II product features & parameters

product features

No tedious hydraulic testing, just fill the oil with power on
Integrated circuit board control, beautiful, efficient, and stable



High-strength materials, safe, stable and durable

Equipped with drop alarm buzzer system, safety reminder is always in mind


Technical data:

drive mode	Oil Cylinder direct drive
Rated capacity	3500 Kg≈7700 Kg
Lifting height	1850mm
Lowest height	110mm
Platform length	1475mm-2085mm
Platform width	650mm
Total width	2100mm
Power	110V
Hydraulic oil	46#Anti-wear hydraulic oil
Air pressure	10 bar

Diagram(unit:mm)



Electrical system schematic diagram10-1



Electrical system schematic diagram(220v 1phvoltage)

Detail drawing of electrica components

No.	Item	name & specification	quantity
	HK	Combination Switch HZ5-20-4L03	
2	HL	Indicator light AD16-22D(s)/AC220V	
3	F1-F2	fuse(core RT18-32-32A-AM/10x38)	2
4	P4	fuse (core RT18-32-2A-AM/10X38)	
5	SB1、SB3	power switch button LAY37-10(black)	2
6	SB2	power switch button LAY37-20 (black)	
7	M	AC contactor CJX2-1210/AC220V	
8	KT	Time Relay TH3/AC220V 10S	
9	YV	Solenoid unloading valve EVK041/EC1-F-220A-00-00	
10	QV	Solenoid valve 3V210-08-NC-AC220V	
11	SQ	Limit switch AZ7311	
12	M	90L-2F 220V 50Hz 1PH 2.2KW S2electric motor with thermal protection	
13	ST	Motor thermal protector JW67(6A/130℃)	


Introduction of main components, diagram

Working Platform:Chassis Contact Lifting Car Locking Teeth:Safety Mechansm,
Mechanical Locking

Pull Arm:Extended Working Platform

Control cabinet:The control unit provides power output

Cylinder:Actuator.drive the platform up



Chapter III Installation preparation


3.1 open the package:

All the packaging,unloading,transport and disassemble work must be operated by professional technical staff.

Transportation:

Use crane,forklift above 3ton capacity to unloading or move it,to avoid goods from falling,one person need to observethe goods during operation,to to avoid accidents.Goods loaded by cars or ship transportation,Check the integrity of the goods to prevent damage or loss during transportation.If the packaging is damaged during transportation,check the damages according to the packing list to determine the damage to the goods and the missing parts,and notify the carrier at the same time.

The machine is a heavy cargo,manual unloading or handling methods cannot be considered.Work safety is particularly important.In addition,during the loading and unloading process,the loading of goods should be carried out as shown in the diagram.



Storage:

Machines should be stored in indoor warehouses,and waterproof treatment should be done for outdoor storage.Van truck should be used during transportation.If by sea usually by shipping containers.During transport,the control cabinet must be placed upright with othercargo to avoid cargo squeeze.

3.2 Installation preparation

Note: basic requirements

·Connect power supply

·Connect Compressed air intake pipe($\phi 8 \times 6 \text{mm}$)

3.3 Installation:


·work should only be carried out by professionals. The following instructions should be read and followed carefully to prevent machine damage and personal injury.

·Only authorized technicians should install the lift.

3.3.1 Installation requirements:

The lift must be installed according to the specified safety distance from walls, columns and other equipment (Fig 4). The minimum distance from the ground is 1000mm, in order to prevent prohibited conditions and facilitate work. Sufficient space for the safety passage should also be considered. The installation site should have power supply and air source connected to the console position in advance, and the indoor height should not be less than 4000mm.

Install in any indoors ground, if ground level meets requirements and enough weight bearing capacity ($\geq 25 \text{MPa}$). When the machine is installed, there should be enough light to ensure the safe operation of debugging and maintenance, and it should also avoid strong stimulating light affecting the sight of personnel and causing eye fatigue.



Before installing the lift, the integrity of the arrival of the goods should be checked. The movement and installation of the lift should be carried out by professionals. Transport and storage of the machine see Transport and storage

3.3.2 Electricsystem installation

Electrical installation work should only be performed by professionals qualified in electrical operation.



- Open the top cover of the control box first
- Power cable connection: Connect the 380V 3ph four-wire power cable (3×2.5mm²+1×1.5 mm² cable) to the console L1,L2,L3 and the PE ground wire on the incoming terminal to the ground, on the marking bolts, and then connect to the grounding marking bolts at the bottom of the two platforms (Figure 1)
- If it is a 220V single-phase power supply, connect the 220V power cord to the PE ground wire on the N.L terminal of the console (Figure 2)




图 1




图 2

Connect the O8×6 compressed air pipe to the air inlet of the double oil-water separator in the console.






Figure 3 (Double oil-water separator)

Schematic diagram of Air pipe connection:




No	200	Mam	quantity
1	201	Air source treatment two-piece	1
2	202	Joint APL6-02	1
3	203	acoustical damper	1
4	204	Plug 1/8"	1
5	205	Solenoid 4V210-08-DC24V	1
8	206	Plug 1/4"	1
9	207	Airhose PU0604	10m
10	208	Ttype connector APE6	1
11	209	small cvlinder	2
12	210	joint APL6-01	2
13	211	Joint APLB-02	2

Schematic diagram of the oil pipe joint



No.	Htem	Name	quantity	Remark
1	1#	2-180 Cydinder	6	220m
2	2#	2-180 Cylinder	1	1360mm
3	3#	Odode	1	1430mm
4	4#	2-180Cylinder	1	1520mm
5	5#	2-180 Cylinder	1	3350mm
6	6#	2-180 Cylinder	1	3450mm
7	7#	2-180 Cylinde	1	3600mm
8	a	Throtlejoint assembly	2	
9	b	throtte body	2	
10		2-M14 right anglejoin	3	
11	d	-M4ioht angk loin	3	
12	e	16Combinaton pad	4	
13		Electriccontrol box	1	

Hydraulic Tube Assembly:



No.	Name	No.	Name
1	electric motor (motor)	9	nghtandi jgint
2	Oil supply connector	10	nghtandejsint
3	unloading solenoid valve	11	apsW
4	Throttle speed control valve	12	stem
5	Combination valve plate	13	的 h
6	valve body assembly	14	Eme gnydretun vche jmarual
7	Oil standard cap	15	Rlietwelsjstem pesfiredtpinght
8	exhaust return port	16	ecthc motor Imoo

Chapter IV Adjustment



After adjusting the position of the platform, connect the electric circuit, air circuit, follow the procedure below:


Open the control box cover and inject 10L 46# anti-wear hydraulic oil into the oil tank with a funnel (hydraulic oil provided by the user)

When injecting hydraulic oil, ensure that the hydraulic oil is clean, and prevent any impurities from entering the oil circuit, causing oil circuit blockage and electrical failure or Solenoid valve malfunction

Turn on the power, close the main power switch, press the "Up" button, and check whether the rotation of the motor is correct (rotate clockwise from top to bottom). If it is reversed, cut off the power and adjust the power phase sequence.



When power is turned on, there is a possibility of high voltage electrical shock inside the console. Only authorized and qualified personnel with electrical operation qualifications and experience should work and prevent the risk of electric shock.



1 Electric motor(motor) 2 Oil supply port 3 Unloading solenoid valve
 4 Throttle speed control valve 5 Combination valve plate 6 Valve Body Assembly
 7 Oil gauge cap 8 Exhaust Return Port 9 Right Angle Fitting 10 Straight Fitting
 11 Cap Nut 12 Valve Stem 13 one way valve 14 Emergency oil return port (manual)
 15 Relief valve/system pressure regulating valve 16 Oil tank (oil volume:14L)

No.1(21)main cylinder hydraulic oil pipe No.2(F1/F2)sub cylinder hydraulic oil pipe

Instructions for use and adjustment

normal working condition. The main circuit Z1 of the combined valve plate 5 is open and the secondary circuit F1/F2 is closed.

In the closed state, if the hydraulic system has a lifting fault or a power failure, the hydraulic jack will be opened after the safety gear top is opened.

Rotate the emergency oil return 14 to lower the machine. The descending speed of the system can be adjusted by adjusting the throttle speed control valve 4. Adjust the no-load speed between 45 and 55s.

Adjust the oil replenishment and leveling state of the oil cylinder. When the working surface of the sub platform is low, the sub oil cylinder needs to be supplemented with oil. Then, after the main valve Z1 of the combined valve plate is completely closed, the auxiliary circuit valve stem F1/F2 is adjusted to the open state, and press the up button to fill and level the oil; if the oil is too much, press the down button to remove a part of the auxiliary oil cylinder. Oil will do. After the adjustment is completed, the valve stem of the combined valve plate is rotated back to the normal working state, and the oil filling and leveling is completed.

Check whether the safety device of the safety claw of the two main platforms is flexible and reliable, whether there is leakage on the oil circuit or air circuit. Use an electric hammer to drill $\phi 16$ impact drill bit from the bottom hole of the platform into the ground 120 mm deep hole (Fig.4) and clean the hole. Use a light hammer to install the anchor bolt into the hole (do not need to install the anchor bolt center expansion nail, and then install it after the level adjustment is completed) Figure 5




Fig.4




Fig.5

Raise the platform to the fifth or sixth teeth and press the "lock" button, put left and right platform insurance teeth to the safety teeth.

Use a clear level tube or a spirit level to check the level of the left and right platform level (Fig.6)




Image 6

If the platform is not flat due to the uneven foundation, use a wrench to adjust the adjusting bolts on the base plate of the main platform (Fig.7)




Fig.7




Fig.8

After the horizontal adjustment is completed, insert the expansion nail in the center of the anchor screw, and hammer it into the expansion nail with a heavy hammer.

Tighten the anchor bolts and nuts

When the concrete curing period has not expired, it is not allowed to hammer into the center expansion nail of the anchor bolt. After adjusting the level, the gap between the bottom plate and the ground must be filled with cement mortar and compacted.

Low level adjustment: When the main platform is lowered to the lowest position, the low level of the platform can be adjusted by adjusting the support adjusting screw at the lower end of the main platform (see Fig.8)

Loosen the retaining nut first

Adjust the length of the support screw to the appropriate position

Re-tighten the nut



4.2 test

No-load test

Connect power switch

Press on button, watch if 2 main platform rise Smooth and synchronised.

Raise to the highest position and observe whether the top limit switch of the platform is accurate and reliable

Press the lock'button to observe whether the safety

Mechanical lock is properly seated



During the test, no people or other objects are allowed to go up and down the lift or in the specified area. Stop the lift on time when abnormality is found, and re-test after the fault is eliminated.

Loading test:

Drive the vehicle that does not exceed the maximum lift weight onto the platform, tighten the brakes, and leave the vehicle and platform

Press the "Up" button to raise the main platform and observe whether the main platform is stable and synchronized

Check whether the lift frame and hydraulic pump station has abnormal noise

Raise to the highest position and observe whether the highest limit switch of the platform is accurate and reliable

Press the 'Lock' button and observe whether the safety pawl is properly seated



During the test, no people or other objects are allowed to go up and down the lift or in the specified area. Stop the lift on time when abnormality is found, and re-test after the fault is eliminated.



Only trained machine operators should operate the lift. Before operation, check the following precautions:

Operation Notes:

Before work, remove obstacles around and below it.

When lift raise and lower, there should be no people in the specified area of the lift and the vehicle above and below the machine and on the platform.

Do not lift vehicles or other goods that exceed the lift capacity of this machine.

When lifting, the brakes of the vehicle should be pulled closer, and anti-skid devices such as anti-skid triangles should be placed on them (user-supplied).

During the lifting process, observe whether the lift platform is synchronized at any time. If any abnormality is found, stop it on time, check and eliminate the fault before it can be put into use.

When doing maintenance or four-wheel alignment inspection and adjustment, press the lock button to lock the safety claws of the two platforms at the same level. Only after the locking operation can personnel enter the lift and work under the vehicle.

During the descending operation, pay attention to observe whether the two safety claws and the safety teeth are completely disengaged, otherwise stop descending.

When it is not used for a long time or overnight, the platform should be **lowered to the lowest position on the ground, drive away the vehicle, and** cutoff the power supply.

Electrical Operation Instructions

Rise:

Press the "Up" button, the oil pump runs. the hydraulic oil is sent to the hydraulic cylinder platform through the main engine or sub-machine solenoid valve to rise

Down:

Press the down button, the oil pump running platform will rise first, and then open the safety (slave platform) and rise first (release the safety claw). After a delay of 1-2 seconds, the motor stops running, the cylinder safety is opened, the oil return solenoid valve is opened, and the lift is lowered.

When the platform reaches the highest limit and stops at the limit, at this time, press the "Down" button for 1-2 seconds

the platform can be turned to descend (no ascending action)

Lock: Press the lock button. The electromagnetic oil return valve returns oil and falls into the mechanical insurance

Chapter V Maintenance

Lift maintenance and maintenance should be performed by trained operators



At all the supporting shafts of the machine, use the oil can to add oil once a week

For moving parts such as safety racks and upper and lower sliders, add grease once a month

The hydraulic oil must be replaced for the first time when the new machine is used for three months. After that, it should be replaced once a year and the oil inlet and oil filter of the oil filling port of the pump station should be cleaned. The oil level should be kept at the upper limit for a long time.

The structural strength of the lift must be judged by a professional department once every five years of use.



The oil cup and water cup of the gas oil-water separator must be cleaned every quarter, and the oil in the oil cup must be replaced

When replacing hydraulic oil, the machine must be lowered to the lowest level, and the old oil in the oil tank must be emptied. When filling new oil, it should be filtered by an oil filter

Check the reliability of limit switch action every day

Check the flexibility and reliability of the pneumatic safety device every shift




Machine troubleshooting must be performed by trained and experienced technicians

Malfunction and Method of exclusion

fault phenomenon	Cause and phenomenon	Troubleshooting method
The motor doesn't turn when it is working up	The power supply is abnormal	Check to exclude and connect the wires
	The AC contactor of the main circuit of the pump motor does not pull in	If the motor can work by forcibly pressing it with an insulating rod, check the control circuit, if the voltage at the coil terminal of the contactor is normal, check the main circuit, if the voltage at the coil terminal of the contactor is normal, check the main circuit, if the voltage at the coil terminal of the contactor is normal, check the main circuit
	Limit switch circuit fault	If the limit switch disappears after the limit switch terminal S01 or S0.2 is short-circuited with the wire, check the limit switch, wire and adjust or replace the limit switch
	button switch failure	Check button contacts, lead and exclude
When pressing up, the motor rotates but does not rise	Motor reverse rotation	Swap the phase sequence of the incoming power line
	Light load can rise, Heavy load does not lift	Raise the safety pressure setting of the relief valve by a small amount of right-hand rotation, and the spool of the solenoid valve is dirty, Clean the spool
	Insufficient hydraulic oil or incorrect label	Replenish or replace hydraulic oil
	The solenoid valve manual oil return screw is not tightened	Tighten the oil drain screw of the main unit or subunit
	Solenoid valve plug burned out	Replace the main unit or sub unit Solenoid valve plug
The lift does not descend when the descend button is pressed.	Safety paw does not disengage the safety tooth	Slightly adjust the long-time relay delay time
	Safety claw does not lift	Air pressure is not enough. The safety claw is stuck or the trachea is broken, Adjust air compressor pressure Check air pipe and rehook
	Solenoid valve does not work	If the solenoid valve is energized but does not work so that the air circuit cannot pass, check or replace the solenoid valve
	Down solenoid valve not working	Check the plug and coil of the descending solenoid valve, and check whether the copper nut at the end is tightened to the right, etc
	Anti-blocking valve blocked	Remove the anti-explosion valve in the oil inlet hole at the bottom of the main engine or sub-cylinder and open the oil
The lift descends very slowly under normal load	The viscosity of hydraulic oil is too large or frozen or deteriorated (winter)	Change to hydraulic oil or increase the room temperature according to the instructions
	The explosion-proof valve to prevent the oil pipe from bursting is blocked	Remove or close the intake pipe so that the safety claw does not lift up and lock it. Remove the explosion-proof valve in the oil inlet hole at the bottom of the cylinder and clean it up
The left and right platforms are not synchronized and the height is not equal	The air in the cylinder is not exhausted	See adjustment Operation
	Oil leakage at the oil pipe or joint	Tighten the joint or replace the oil seal Refill oil for leveling
	The shut-off valve is not tightly closed, and need to be refilled every day.	Replace the oil filling shut-off valve, and then refill the oil for leveling
Abnormal noise during work	Lack of lubricating oil	All joints and moving parts (including piston rod) are lubricated with oil
	Foundation or machine twist.	Readjust the machine level Fill (mat) foundation
Press down and it always up	The time relay is loose or damaged	Reinsert the time relay or replace it.

Chapter VI product explosive diagram

Main platform explosive diagram



main platform parts list:

No.	Item	quantity	No.	Item	quantity
	HGT730-1H0-Abesehod	2	29	HGTTJ0-80-17-Arampwheel	8
2	HGTJ0-]-004 tonotsidesisa	2	30	HGTTJ0-80-14-ACJlinder spacer roler A	2
3	HGT73-50-044upautsies50	2	31	TL7632AF-00-14Shaft lock plate	4
4	HGTJ-7-0 • Atum	2	32	Main cylinder	2
5	HGTI41-00Aupimrsis0	2	33	Subcylinder	2
6	HGTJ-0-00-4dom mersis0	2	34	HGTTJ0-90-05aircylinde	2
7	HGT731-10-401Sstyathnstonethon	2	35	Expansion boltM16X120	8
8	HGT7第10-2Strbepto ding	2	36	Hexagon CountersunkHeadScrewsM8X16	36
9	HGT70t-0-kasstng m	2	37	GB/T818-2000 Cross recessed pan head ant nailM5x	4
10	HGT71-7-0-4Wngddmbing	2	38	GB/T78-2000Hexagon socket, end fixing nailM8x12	4
11	HGT73-72-004Wngatdmngpibakets	4	39	GB/T818-2000Cross recessed pan head buttonM5x12	8
12	T-HHamwngp	2	40	GB/T818-2000Cross Recessed Pan Head NailsM5 X20	2
13	HGTTJ1H0H4gd	8	41	GB/T93-1987Ouas-type dastic washerSx1	10
14	HGTI-3-囍hsinghdb	2	42	GB/T95-2002 Hat Washer ClassC 5x1	10
15	HGT70-400-3QJhtr的	2	43	JB/T79404-1995 press fit oicup 8	40
16	HGTJ1-3)-30-depushshl	2	44	SF2-282530	4
17	HGT7H-60hder serdr	2	45	SF2-343036	4
18	HGT71-0HEcandtheansha	4	46	SF2-343033	8
19	HGTJ4H5nsstnsimshf	2	47	SFZ-282525	8
20	HGT70-0lnderfid stat	4	48	SF2-403660	8
21	HGT71-30-ine sher shat	8	49	GB8941-86 Shaft RetainingRing Type A 25	12
22	HGTJ0-41Hgiasafied shl	8	50	GB8941-86 Shatt Retaining Ring Type A30	8
23	HGTJJ-90-1bhingpe	16	51	GB8941-86 Shaft Retaining Ring Type A32	4
24	HGT70-0-2-ARdrnerkee	2	52	GB89416Shaft RetainingRing Type A12	16
25	HGTTJ0-0-11And	4	53	oil pipe	2
26	HGTJ)-3-ntrshtt	2	54	Limit switch	1
27	HGT20-0-15Ame fon bnghl	2	55	SF2-343030	4
28	HCHJ-0-134Alampotnshngsh	8	56	SFZ-363252	4